

## XIX. MAINTENANCE

All our diffusers are made of high-quality resistant materials without a natural fibre admixture. The used material is specified when your order is technically processed. The diffusers made of permeable fabric (PMS, PMI, PLS, PLI, PMB, PMT) can be washed in a common industrial washing machine. Impermeable fabrics (NMS, NMI, NLS, NLI, NMT) require a gentle mode washing, fabric NHI, NHE, and NMD hand washing only. If the washed diffuser has tyres, braces or turn-buckles, these solid elements must be removed before the washing process. Induction surface dirt (see article XIII) can be vacuumed, washing is unnecessary.

### The process of washing:

Observe the set maintenance symbols of the particular product thoroughly before you wash it. The washing labels are sewn in in the diffusers by the zips.

### We recommend:

1. Wash the diffusers with common detergents (dosing according to the directions for use), the effect of washing is enhanced if the diffuser is turned inside out. We advise you to repeat the washing up to four times acc. to level of contamination, or to use more powerful washing powder. A special detergent (we will recommend one by request according to the particular dirt) should be used if the fabric is badly soiled.
2. Use a disinfectant only if it is essential according to the local service instructions. The chemical composition of the disinfectant must not harm the diffuser fabric (see maintenance symbols). Observe the producer's dosing instructions.
3. Rinse the diffusers in clean water.
4. Spin-dry the diffusers gently, install them and finish drying by the air flow from the ventilator.

### Symbols key:

|  |   |
|--|---|
|  | max. temperature for washing 40°C<br>normal mechanical action normal rinsing<br>normal separating   |
|  | gentle washing in a washing machine,<br>maximum temperature 40 °C, gentle mechanical action,<br>rinsing in water cooling down, gentle spin-driing                           |
|  | washing only by hands product must not be washed<br>in washing machine<br>max. temperature 40°C cautious handling   |
|  | product must not be whitened<br>with detergents disengaged chlorine   |
|  | dry in a drum-drying machine<br>use lower temperature of drying   |
|  | product can't be dried in a drum-drying   |
|  | ironing within of max. temperature<br>of ironing surface 110°C, cautious<br>with steam ironing  |
|  | product must not be ironed<br>steaming is inadmissible  |
|  | product must not be dry cleaned the stains<br>must not be removed by organic solvents   |
|  | product can be dry cleaned with tetrachlorethen,<br>monofluortrichlormethan and all<br>solvents mentioned with symbol F<br>usual cleaning progresses are without any limits |